



leaf kit

			you have		you need	you have		you need	
				#			#		
Mitsubishi									
L200 KAOT	06-15	+600		xxx		xxx		77170	31507
L200 KAOT	06-15	+300		xxx		xxx		77162	31516
Nissan									
Navara D40	11/05-	+600						77154	31579
Navara D40 +60 mm	11/05-	+300						77166	31504
Patrol K160	80-89	+140		77001		31562		77101	04/2008 31561
Patrol K260	90-	+140		77021		31560		77101	04/2008 31561
Suzuki									
Samurai/SJ, Long Body	85-	OE						77120	31533
Samurai/SJ, short	85-	+150						77120	31533
Samurai/SJ, Diesel	85-	OE		77020	06/2008	31553			
Samurai/SJ, Gas	85-	+60		77020	06/2008	31553			
Toyota									
Hilux	05-	+400kg						OE/ 77175	31527
Hilux +60mm	05-	+400kg						77176	31527
Landcruiser BJ/FJ 40/42 Softtop	69-86	+150						77113	06/2008 31531
								77613	06/2008
Landcruiser BJ/FJ 40/42	69-86	+150		77013	06/2008	31532			
Landcruiser BJ 70/73	84-96	+150		77008		31534			
Landcruiser BJ 70/73	84-96	+100						77108	31531
Landcruiser PZJ-HZJ 70/73/75	90-99	+150		77008		31534			
Landcruiser PZJ-HZJ 70/73	90-99	+100						77108	31531
Landcruiser HZJ 76	07-	+350						OE	31570



leaf kit * leaf kit * kit lames additionnelles * kit de hoja adicional de ballestas * kit foglio balestre *



zusätzliches Gewicht pro Achse * additional weight per axle * poids additionnel par essieu * peso adicional por eje * peso addizionale per ponte

#

nur geeignet für trail master Federn ab diesem Datum * only fits trail master springs from this date on *
Ne s'applique qu'aux ressorts trail master à partir de cette date. * Solo compatible con ballestas trail master a partir de esta fecha * monta solo su molle trail master da questa data in avanti